








**Parts List:**

- A. Side Posts (2)
- B. Crossbars (2)
- C. Base Bars (2)
- E. Ground Anchors (4)
- F. Net (1)




1. Weave **Top Crossbar (B)** (marked with 'Warning' label) through top part of **Net** (marked "Top") in an over-under pattern. Then weave **Bottom Crossbar (B)** (has no labels) through bottom of **Net**.

2. Weave one **Side Post (A)** through the left side of the net, then repeat on the right with the other **Side Post**, and attach top-end of **Side Posts** to **Top Crossbar (B)**.



3. Weave one **Base Bar (C)** through the left side of the base of the net, then repeat on the right with the other **Base Bar**. Attach **Base Bars** to bottom of **Side Post (A)** and **Bottom Crossbar (B)**.

4. Secure the goal onto the field with **Ground Anchors**.



**CONSUMER PRODUCT SAFETY ALERT**

Goals can tip over and cause injury when not properly anchored!

**SAFETY SUGGESTIONS / GUIDELINES:** Securely anchor goals at all times. Never climb on the net or goal framework. Disassemble and safely store goals when not in use. Inspect hardware and nets before every use. Replace damage or missing parts immediately. Do not leave assembled goal unattended. Instruct players on the safe handling of and potential danger associated with the goal.