

agora Half-Moon Pop-Up Goals



Caution!

Goal opens very quickly! Use extreme caution when opening & closing and always secure safety straps when closed.



1 REMOVE FROM BAG.



2 OPEN SAFETY STRAPS.



3 GRAB BOTH HANDLES FIRMLY.*
*OPENS VERY QUICKLY! Do not open near children or animals



4 TO OPEN, MOVE HANDLES APART.*
TO CLOSE, TWIST BOTH HANDLES 90° COUNTER-CLOCKWISE AND BRING HANDLES TOGETHER.
*OPENS VERY QUICKLY! Do not open near children or animals



5 ANCHOR AND ENJOY!