



AGORA ADJUSTABLE TRAINING REBOUNDER (SA-GK45)




Parts List:



- A. Top Bar (1)
- B. Side Posts (2)
- C. Bottom Bars (2)
- D. Curved Side Posts (2)
- E. Tension Screws (2)
- F. Nets (2)
- G. Bungee Straps (48)
- H. J-Hook Anchors (4)
- I. Goal Bag (1)



1. Assemble top bar (A) & bottom bar (C) to side posts (B).




2. Assemble side posts (D) to the other bottom bar (C).




3. Connect both pieces (ABC & DC) using tension screws (E).

NOTE: Tension Screws are intended to hold parts together only, not to tighten them.



4. Attach both nets (F) to top bar (A) using bungee straps (G). Make sure the longer net is placed on the longer side (DC).


TIP: To increase net tension, pull net squares (farthest to the left or right moving inward) one square at a time until desired tension is achieved, then attach bungee net straps.



6. Attach the remaining sides of the nets to frame using remaining bungee straps.

NOTE:

As you adding more bungee straps net may appear small, but net will stretch providing more tension.



8. After attaching nets to assembled frame, use anchors (H) to secure rebounder at desire position & angle.

CONSUMER PRODUCT SAFETY ALERT Goals can tip over and cause injury when not properly anchored

SAFETY SUGGESTIONS / GUIDELINES: Securely anchor goals at all times. Never climb on the net or goal framework. Disassemble and safely store goals when not in use. Inspect hardware and nets before every use. Replace damaged or missing parts immediately. Do not leave assembled goal unattended. Instruct players on the safe handling of and potential danger associated with the goal.